

# MAXIMIZING BATTERY LIFE

## **Avoid extreme ambient temperatures**

Your device is designed to perform well in a wide range of ambient temperatures, with 62° to 72° F (16° to 22° C) as the ideal comfort zone. It's especially important to avoid exposing your device to ambient temperatures higher than 95° F (35° C), which can permanently damage battery capacity.

## **Store it half-charged when storing long term**

If you want to store your device long term (e.g. summer breaks), two key factors will affect the overall health of your battery: the environmental temperature and the percentage of charge on the battery when it's powered down for storage. Therefore, we recommend the following:

- Do not fully charge or discharge the battery - charge to around 50%.
- Power down the device.
- Store in a cool moist-free environment less than 90° F (32° C).
- Top up charge to 50% every 3 months.

## **During regular use**

Do not run battery completely flat and do not leave product connected to charger when fully charged.

