Installation and user guide for C-Pen with Android



IMPORTANT NOTE:

C-Pen 3.5 contains a Lithium-Ion battery. This battery type should NOT be uncharged for a longer period. If the C-Pen 3.5 is not used for a longer period, make sure to charge the battery every second month to keep the battery in shape!

Installation Guide for C-Pen with Android.

NOTE: if reading this online, click on images for high resolution.

The digital highlighter model C-Pen 3.5 is compatible with Android devices.

Requirements:

- A digital highlighter, product model C-Pen 3.5 (<u>www.cpen.com</u>)
- An Android smartphone or Tablet with Android 2.2+, 3.x or 4.x
- Supporting apps per below

Apps:

<u>C-Pen Core</u> is a **required** app when using C-Pen 3.5 with Android. C-Pen Core runs in the background and activates itself when a C-pen 3.5 is connected. There is no user interface except for Settings (details below).



<u>C-Pen Note</u> is an app that features note taking (text files), speech (using Android system TTS) and sharing of notes/files through messaging and/or cloud drives. C-Pen Note also features interfaces to Google Search and Google Translate

providing users immediate "in-app" search and translation results.

NOTE: The app **C-Pen Note** requires Android 3.x or 4.x.

AnySoftKeyboard (C-Pen edition) is an optional app and is only required if the intention is to use the C-Pen to scan text directly into third party apps (i.e. NOT C-Pen Note).

Hence, to get C-Pen working with your Android device you'll need to install either:

• C-Pen Core + AnySoftKeyboard (C-Pen edition)

OR

• C-Pen Core + C-Pen Note

OR

• C-Pen Core + C-Pen Note + AnySoftKeyboard (C-Pen edition)

Installing C-Pen Core and C-Pen Note:

- Open Google Play on your Android device.
- Search Google Play for "cpen core" or use your Android QR scanner on the QR code embedded in the image to the right.
- Complete C-Pen Core installation.
- Open/start C-Pen Core after installation and walk through the intro images



- Reaching the last image, click the *Download* button if you like to install C-Pen Note – follow on screen information to complete installation.
- If not installing C-Pen Note click the X to close.

5. Download a OR	ugh intro images and install C-Pen Note
5. Click the X	to close the intro
Mak	e a choice!
	Instant

Optional - installing AnySoftKeyboard (C-Pen edition):

- Download and install *AnySoftKeyboard* (*C-Pen edition*) using the QR code above or locate the C-Pen Core icon on your Android device and click to start C-Pen Core.
- If not using the QR code, go to C-Pen Core Settings → HOST Settings → and click on AnySoftKeyboard (C-Pen edition) to download and install it.

корілт	
	Alcost C-Pen Ex Andraid Texa anticanal animat para 2 Pen mitrare derivations and surfa C Pennya multial parately manual taxis of an application.
1617	
	How to use C-Pen Coro for Anthold
2-7091	nvve
	Carteri carendori IIM.e Recenteri
	C Perclasher status (%)
6-800	H11994
	Maria Languages Datastatist Scipulge Ref will be card to varied
	00File guages stati spolinguage
	Punchise Indiani action sent function function action
	C-Pen scan separater
sec.	CTTHER.
	Education in the section of the sect
	Disebuth pair true exceptional a language free
	AnySoftKeyloant (D-Pen adition) Manualmosteriations: Per boards for hit organic
	ingut mediad actings Dealer by Delaydeard (C. Pereiller) must anticit a state the scatted bei and deter aller applications
uase	
	B.B.A. For many correct Agramment
-	

- NOTE: your Android device may block apps from unknown sources (ref image to right).
- If that 's case, go to Android Settings → Security and allow Unknown sources.



- Finally we need to **Activate** AnySoftKeyboard and select it as default Input Method.
- Go to Android Settings → Language and Input.
- Check the box beside AnySoftKeyboard to activate it as Input Method
- Under *Keyboard & Input*, click *Default* and select AnySoftKeyboard to be the default input method.



Bluetooth pairing:

- Make sure Bluetooth is enabled on your Android device (go to Android Settings → Wireless and Networks → Bluetooth).
- Make sure your C-Pen 3.5 is powered off.
- Power on the C-Pen 3.5 by press-and-hold the function button (3-5s) until the blue LED starts to flash.
- In Android Bluetooth settings, press Scan for devices and allow your Android device to find the C-Pen 3.5



 Click on the C-Pen 3.5 text and enter PIN: 1234



C-Pen Note user guide

Pre-requisits:

- The C-Pen and the Android device needs to be paired (Bluetooth).
- C-Pen Core and C-Pen Note apps needs to be installed.
- Access Settings by pressing the three dots in the upper right corner



C-Pen Note Settings:

- *Auto Speak:* if enabled anything you scan will be read out by the system TTS voice immediately.
- TTS Settings: a short cut to system TTS settings allowing easy access to set up the TTS. We recommend using SVOX or Ivona HQ TTS (available on Google Play).
- OCR Language: sets the OCR language used to recognize scanned text.
- *Pen button settings:* assigns a function to the C-Pen function button.
- Advanced Settings: is a shortcut to all settings available in C-Pen Core Settings.
- *Pair C-Pen*: is a pairing wizard for easy pairing of C-Pen and Android device. Click to start the process.
- *Font Settings*: sets the size of the font used in the text notes.

Inst Ta Speech	
Justic Epimole	277
Total To Appreciational Descared where magneting lensi	
TTE-familings	
Child to open	
-Pen Satlings	
009.Language	Britada
Entrol language to be used when some simplessi	
Parinution Setting	Robing _
Salact also happens when 2 Par-Isolani is olicitati	
Advanced settings	
Citals be again	
heir E-Pen	
Blastooth pair	
Chill to pair	
Panti Elar Choser for-incircl loci size	
	54
	N

C-Pen Notes

• This view lists all the notes saved on the device. Click to open or share note.



C-Pen Note view:

- Any text scanned will end up in this text editor view.
- To listen to the text, select and click the *Play* symbol.
- To share the note, click the *Share* symbol.

C C Pentiate		@~* < ==	÷
MACH C-PEOREE	11.4.10, 171		
Title : No Title		10/5/2014	
1			

C-Pen Note Search:

- Any text scanned when in this view will trigger a Google Search and the result will be displayed instantly.
- Requires internet connection.



C-Pen Note Translate:

 Similar to C-Pen Note Search, any text scanned ends up in this view and a translation powered by Google Translate is instantly provided.



Scanning to 3rd party applications

Pre-requisits:

- The C-Pen and the Android device needs to be paired (Bluetooth).
- C-Pen Core and AnySoftKeyBoard (C-Pen edition) needs to be installed.

Scan to 3rd party app:

- Open the application of your choice, e.g. a new document on Google Drive.
- Make sure that AnySoftKeyboard is your chosen Input Method. Pull down the Notification menu and click in *Choose input method*.
- If necessary, change OCR language in C-Pen Core Settings.
- Power on the C-Pen 3.5.
- Scan and enjoy!



